

# *Drain Installation*

## **Standard Installation**

- 1) Remove mounting hardware and tailpiece from drain
- 2) Place a bead of plumber's putty or silicone sealant on the underside of the drain body flange and install drain body through the drain hole of the lavatory.
- 3) From the underside of the sink install the tapered rubber gasket (taper up) followed by retaining washer and lock nut. Carefully tighten lock nut until gasket seats and seal is achieved. (CAUTION: Over tightening could cause damage to sink.) Clean off any excess putty or silicone from flange.
- 4) Apply Teflon tape to threads of tailpiece and thread tightly into drain body.
- 5) Connect drain to P-Trap and test for leaks (NOTE: tailpiece may be cut to length as required)

## **Care and Cleaning Instructions**

Do not use harsh alkali or acid based detergents, abrasive polishes or scouring cleansers. Also do not use any S.O.S. ® pads or Scotch Brite Pads ®. These are scouring tools and will scratch chrome as well as your PVD and Lacquer coated products. This is good advice to use on any plumbing fixture regardless of the material or finish, as stainless can be scratched and colored plastic will develop a dull finish.

Do not leave coffee or vinegar laying in the bottom of sink basin.

After use, please wipe your PVD coated product dry with a clean soft cloth. Wiping is important as it will limit water spotting.

To clean just wipe with a damp cloth and dry with a soft cloth. If necessary regular Windex can be used.

To clean our lacquer coated products follow the above steps or you can use a product from the Flitz Company (800-558-8611) called "Polished Brass Protectant" for coated fixtures.

For additional protection – Spray Pledge furniture polish unto a soft cloth and wipe. Bear Creek Glass warrants that the Lifetime Warranty on our PVD Finish will not tarnish, pit, or discolor.