

Sink Installation

HAND TIGHTEN DRAIN ASSEMBLIES, DO NOT OVER TIGHTEN.

For best results, use Bear Creek Glass Quick Flow drains.

Mounting methods by Sink Style

| | Vessel | Self Rim | Under | Over |
|-------------------|--------|----------|-------|------|
| Classic | X | X | X | |
| Splash | X | | | |
| Ocean | X | | | |
| Fusion | X | X | X | |
| Over Mount | | X | | X |
| Water Bowl | X | | | |

Vessel Mounting: Make countertop hole 2 ¼ "

Self-Rim Mounting: Verify countertop hole shape and size on a piece of plywood or heavy cardboard before cutting countertop. Not recommended for transparent or translucent colors.

Under Mounting:

- Clean under countertop where sink will attach using appropriate type of cleaner for countertop.
- Clean top of rim of sink using rubbing alcohol.
- Allow all surfaces to dry.
- Apply bead of silicone to top of rim of sink.
- Attach sink to countertop using the method or similar method to that below.
- Apply bead of clear silicone to outside rim of sink where it meets countertop.
- Allow to dry overnight.

